125987340.qxp 2007-03-16 11:41 Page 1



Thinking of you

Electrolux

user manual

Tumble Dryer

EDC 77570 W

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 2



Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 3

GB

Welcome to the world of Electrolux

Thank you for choosing a first class product from Electrolux, which hopefully will provide you with lots of pleasure in the future. The Electrolux ambition is to offer a wide variety of quality products that make your life more comfortable. You find some examples on the cover in this manual. Please take a few minutes to study this manual so that you can take advantage of the benefits of your new machine. We promise that it will provide a superior User Experience delivering Ease-of-Mind. Good luck!

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 4

Contents

Safety information 5
Product description 7
Control panel 7
Use 8
Drying rack 12
Drying hints 13-14
Drying programme 15-16
Programme information 17
Care and cleaning 18-20
Something not working 21-23
Technical data 24
Consumption values 25
Installation 26-28
Environment concerns 28
Guarantee/Customer Service . . . . . 29 -33

The following symbols are used in this manual:

Important information concerning your personal safety and information on how to avoid damaging the appliance.

General information and tips

Environmental information

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 5

Safety Information



In the interest of your safety and to ensure the correct use, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid unnecessary mistakes and accidents, it is important to ensure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and make sure that they remain with the appliance if it is moved or sold, so that everyone using it through its life will be properly informed on appliance use and safety.

General safety

- It is dangerous to alter the specifications or attempt to modify this product in any way.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Make sure that small pets do not climb into the drum. To avoid this, please check inside the drum before using.
- Any objects such as coins, safety pins, nails, screws, stones or any other hard, sharp material can cause extensive damage and must not be placed into the machine.
- In order to avoid danger of fires caused by excessive drying, do not use appliance to dry the following items: Cushions, quilts and the like (these items accumulate heat).
- Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the tumble dryer.
- Always unplug the appliance after use, clean and maintenance.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Centre. Always insist on genuine spare parts.
- Items that have been soiled with substances such as cooking oil acetone, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.
- Danger of explosion: Never tumble dry items that have been in contact with inflammable solvents (petrol, methylated spirits, dry cleaning fluid and the like). As these substance are volatile, they could cause an explosion. Only tumble dry items washed with water.
- Risk of fire: items that have been spotted or soaked with vegetable or cooking oil constitute a fire hazard and should not be placed in the tumble dryer.
- Should the appliance power supply cable need to be replaced, this must be carried out by our Service Centre.
- If you have washed your laundry with stain remover you must execute an extra rinse cycle before loading your tumble dryer.
- Please make sure that no gas lighters or matches have accidentally been left in pockets of garments to be loaded into appliance

GB

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 6

Installation

- This appliance is heavy. Care should be taken when moving it.
- When unpacking the appliance, check that it is not damaged. If in doubt, do not use it and contact the Service Centre.
- All packing and transit bolts must be removed before use. Serious damage can occur to the product and to property if this is not adhered to. See relevant section in the user manual.
- The final part of a tumble dryer cycle occurs without heat (cool down cycle) to ensure that the items are left at a temperature that ensures that items will not be damaged.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable
- The appliance must not be built-in.
- If the machine is situated on a carpeted floor, please adjust the feet in order to allow air to circulate freely
- After having installed the appliance, check that it is not pressing or standing on its electrical supply cable, inlet hose and drain hose.
- If the tumble dryer is placed on top of a washing machine, it is compulsory to use the stacking kit (optional accessory).

Use

- This appliance is designed for domestic use. It must not be used for purposes other than those for which it was designed.
- Only wash fabrics which are designed to be machine dried. Follow the instructions on each garment label.
- Do not dry unwashed items in the tumble dryer.
- Fabric softeners, or similar products, should be used as specified by the fabric softener instructions.
- Do not overload the appliance. See the relevant section in the user manual.
- Clothes which are dripping wet should not be placed in the dryer.
- Garments which have been in contact with volatile petroleum products should not be machine dried. If volatile cleaning fluids are used, care should be taken to ensure that the fluid is removed from the garment before placing in the machine.
- Never pull the power supply cable to remove the plug from the socket; always take hold of the plug itself.
- Never use the tumble dryer if the power supply cable, the control panel, the working surface or the base are damaged so that the inside of the tumble dryer is accessible.

WARNING:

Never stop a tumble dry before the end of the drying cycle.

Child safety

- This machine is not intended for use by young children or infirm persons without supervision.
- Children should be supervised to ensure that they do not play with the appliance.
- The packaging components (e.g. plastic film, polystyrene) can be dangerous to children - danger of suffocation! Keep them out of children's reach
- Keep all detergents in a safe place out of children's reach.
- Make sure that children or pets do not climb into the drum.


Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 7


GB

Product description

1. Control panel
2. Drum Light
3. Fluff filters
4. Rating Plate
5. Condenser unit
6. Water reservoir
7. Adjustable feet
8. Rack



Control panel



1. **Programme selector dial**
2. **Delicate button**
3. **Buzzer button**
4. **Dryness button**
5. **Time button**
6. **Start/Pause button**
7. **Delay button**
8. **Indicator lights**
9. **Display**

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:41 Page 8

Use

First Use

Ensure that the electrical connections comply with the installation instructions.

Remove the polystyrene block and any material from the drum.

Before using your tumble dryer for the first time, we recommend that you place a few damp cloths inside the appliance and dry for 30 minutes. There may be dust inside a brand new tumble dryer.

Daily Use

Connect the appliance. Open the door (see picture).



Place the laundry in the drum, one item at a time, shaking them out as much as possible. Close the door. Please check the laundry does not get caught between the door and filter.



Select the required programme

Turn the programme selector dial to the required programme. The light Start/Pause starts to flash.



The selector dial is divided into following sections:

Cotton
Synthetics
Special

Allows you to select electronically controlled or time controlled drying. Turn the dial to the required programme or time. Electronically controlled drying (automatic) The appliance runs these programmes with the help of probes which detect the degree of dampness of the laundry. Simply select the programme according to the type of laundry and degree of drying required. The selector dial can be turned either clockwise or anticlockwise.

At the end of the programme the selector dial must be turned to position O, to switch the machine off.

Attention!

If you turn the programme selector dial to another programme when the machine is working, the lights of the programme progress display start to flash. The machine will not perform the new selected programme.

Programme Option buttons

Depending on the programme, different functions can be combined. These must
be selected after choosing the desired programme and before depressing the Start/Pause button. When these buttons are pressed, the corresponding pilot lights come on.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 9

GB

When they are pressed again, the pilot lights go out.

Select Delicate

Pressing this button allows drying to be performed at a lower temperature, for delicate items.



The corresponding pilot light comes on. This option can also be used for time controlled drying.
DELICATE is only suitable for use with loads of up to 3kg!

Select the Buzzer

When the drying cycle has finished, an intermittent audible signal will sound.



By depressing button the acoustic signal is switched off in the following cases:

- when selecting the programme
- when depressing the buttons
- when the programme selector dial is turned to another position during the programme or when you depress an option button during the cycle
- at the end of the programme.

The corresponding light comes on

Select the Dryness


Press the Dryness button repeatedly, to select the desired option. The relevant light will light up. Laundry becomes dryer from MIN to MAX.



When the programme has finished the pilot lights End is on.

Time button

To select the programme duration after setting the TIME (Tiempo Kit) programme.



You can select a programme duration from 10 mins to 3 hrs in 10- minute steps.
1. Turn the programme knob to the TIME programme. The display will show 0.10 (corresponding to the COOLING programme).
2. Press the TIME button repeatedly until the desired programme duration is shown in the display, e.g. 00.20 for a programme of 20 minutes. If the programme duration is not selected, the duration is automatically set to 10 mins.

Select the Start/Pause




Press this button to start the dryer after having selected the programme and the options. The relevant light will stop flashing. If the programme selector dial is turned to another position, when the machine is running, the buzzer will sound and the programme phase indicator lights will flash. The drum turns alternately in both directions during drying. All drying programmes end with a 10 minute cooling phase (light Cooling is on). You may remove the laundry after this phase.
The display t will show the symbol Long Anticrease, and and illuminate and the buzzer sounds
If the door of the appliance or the small door at the bottom is opened while the programme is running, this button must be pressed again after closing the door in order to restart the pro-

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 10

gramme from the point at which it was interrupted. This button must be depressed also after a power failure and after having reinserted the water reservoir, if it has been emptied in the middle of a programme after lighting up of light .
In both cases the light of the Start/Pause button flashes to remind you that the start button needs to be pressed again.

Select the Delay Start




With the DELAY button, you can delay the start of a programme by between 30 minutes (*30'* and a maximum of 20 hours (*20H*).
1.Select the programme
2.Press the DELAY button as many times as necessary until the required start delay appears on the multi display, e.g. *12H* if the programme is to be started in 12 hours.
3 If *20H* is displayed and you press the button again, the time delay will be cancelled. The display will show *0'* and then the duration of the selected programme.
4.To activate the delay timer, press the START/PAUSE button. The amount of time remaining until the programme is set to start is continuously displayed (e.g. *12H*, *11H*, *10H*, … *30'* etc).
If you wish to add some laundry while the machine is performing the countdown, after having done so and having closed the door, press START/PAUSE again, in order to allow the machine to complete the remaining countdown time.

Display

The display shows the following information:


Duration of selected programme After you have selected the programme, its duration (in hours and minutes) appears on the display. It is calculated automatically on the basis of the maximum load accepted for each type of fabric and of the required degree of drying.



When the programme starts, the remaining time is displayed every 5 minutes.


Delayed start

If you have selected a delay time by means of the relevant button, the display shows it for 3 seconds; then it shows the duration of the previously selected programme. The countdown is displayed every 30 minutes until it displays “90 minutes” and then hour by hour.




End of programme

A flashing zero indicates the end of the programme and it is displayed after the “anticreasing” phase.



Incorrect option selection

If you select an option that is not compatible with the programme you have selected, the display shows *Err* (error).



This code will reappear during the execution of the programme if you

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 11

GB

press one of the option buttons or turn the programme selector.

Alarm code

In case of a functional anomaly, the display

shows an alarm code (e.g. E21).



"Drying"

This symbol appears on the dispay that the appliance is in the drying phase.

"Cooling"

This symbol appears on the dispay that the appliance is in the cooling phase. At the end of drying, there is a 10 minute cooling phase to cool the laundry.

"Long Anticrease"

This symbol appears on the dispay at the end of the cooling phase, during the anti-creasing phase and at the end of the programme.

Indicator lights

These lights indicate the following functions:

"Water reservoir full" light

This light comes on at the end of the programme to remind you that the water reservoir must be emptied out. If this light illuminates during a programme this means

that the water reservoir is full. The buzzer sounds, the programme stops, the light of the Start/Pause button flashes. "Filter cleaning" light

It comes on every 80 cycles to remind you that the condenser must be cleaned. "Condenser cleaning" light

This light illuminates at the end of the programme to remind you that the filters must be cleaned.

At the end of the programme

All drying programmes end with a 10 minute cooling phase. You may remove the laundry after this phase. The lights and , illuminate.

The display shows a static zero. If the laundry is not removed at the end of the cycle, the dryer performs an anti-creasing phase (duration: 30 minutes maximum).

If you do not remove the laundry, the dryer will stop automatically at the end of

the anti-creasing phase. Lights and remain lit and the buzzer sounds for 2 minutes. If you do not intend to carry out another wash, close the water tap. Leave the door open to prevent the formation of mildew and unpleasant smells.

Turn the programme selector dial to "O" to switch the machine off. Remove the laundry from the drum and carefully check that the drum is empty. The appliance is switched off.

Remove the laundry.

If you open and then close the door before turning the selector dial to "O" all the lights corresponding to the phases making up the performed programme come on.

After each use

- Clean the filters.
- Empty the water reservoir

Important!

If the drying programme has to be stopped before it reaches the end, we recommend that you turn the programme selector dial to position Cooling and wait until the end of this cooling phase before removing the laundry. This will avoid a build-up of heat inside the appliance.To do this first turn the dial to "O" and then to Cooling and depress Start button.

Modifying the programme

To change a programme which is running, first cancel it by turning the programme selector dial to "O". Select the new programme and press the Start button.

Downloaded from www.Manualslib.com manuals search engine


125987340.qxp 2007-03-16 11:42 Page 12

Drying rack

For first removing of the rack. please refer to the instructions for use.

The dryer drum must be empty!


1. Open the loading door.
2. Insert the rack. Remove the rack from the drum at the end of drying. Lift the rack horizontally in the drum. Guide the rack down until the support bracket at the front rests on the opening.



3. Place the washing on the rack:


– Spread the garment out in the rack and roll it up, without squashing or folding it..

– Place sportshoes on the rack with the board turned up.



Important: Take out the insoles and place them beside the shoes on the rack. Tie the shoelaces.

5. Select the required programme run time, settable with an interval of 10 min, from 30 min. up to 180 minutes. Press the ⏲ button as many times as necessary until the required programme running time is shown in the display.



6. Press the START/PAUSE button. The programme is startet.
7. At the end of the drying programme open the loading door and remove the garments or shoes.
8. Turn the programme selector to “**O**”.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 13

Drying hints

GB

Before loading the laundry

Never tumble dry the following:

Particularly delicate items such as net curtains, woollen, silk, fabrics with metal trim, nylon tights, bulky materials such as anoraks, blankets, eiderdowns, sleeping bags, feather quilts and any items containing rubber foam or materials similar to rubber foam.

- Always follow the instructions on garment labels:

  may be tumble dried

  normal drying (high temperature)

  delicate drying (low temperature)

  do not tumble dry
- Close pillowcases and covers with fasteners to prevent small laundry items getting tangled inside them. Close press studs, zips and hooks and tie belts and apron strings.
- Sort laundry according to type and degree of drying required.
- Do not over-dry laundry, this avoids creasing and saves energy.
- Avoid drying dark clothes with light coloured fluffy items such as towels as they could attract the fluff.
- The laundry must be thoroughly spun before tumble drying.
- Easy-care items, too, e.g. shirts, should be briefly pre-spun before drying (depending on crease resistance approx. 30 seconds or using the special brief spin programme on your washing machine).
- Knitted textiles (knitted underwear) may shrink a little during drying. Please do not overdry items of this type. It is advisable to allow for shrinkage when choosing the size of new purchases.
- You can also put starched items into your dryer. However, to achieve the desired starched effect, choose the programme “iron dry”. To remove any starch residues, wipe out the internal drum after drying with a moist cloth and then rub it dry.
- To avoid a static charge when drying is completed, use either a fabric softener when you are washing the laundry or a fabric conditioner specifically for tumble dryers.
- Remove the laundry when the dryer has finished drying.
- If individual items are still damp after drying, set a brief post-drying time, for at least 30 minutes. This will be necessary particularly for multilayered items (e.g. collars, pockets, etc.).

  Do not dry wool in the dryer. May become entangled! After air-drying, wool may be dried with the WOOL CARE programme.

Make sure that no metal objects are left in the laundry (e.g. hair clips, safety pins, pins).

Button up pillowcases, close zip fasteners, hooks and poppers. Tie any belts or long tapes.

Remove persistent stains before washing.

Rub particularly soiled areas with a special detergent or detergent paste. Treat curtains with special care. Remove hooks or tie them up in a bag or net.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 14

Maximum loads

Recommended loads are indicated in the programme charts.

General rules:

Cotton, linen: drum full but not too tightly packed;

Synthetics: drum no more than half full;

Delicate fabrics and woollens: drum no more than one third full.

Try to load to the maximum capacity of the machine as small loads are uneconomical

Load

It is often difficult to estimate the weight of items to be dried. We therefore recommend that you adopt the following guidelines:

- cotton, linen: drum full but not too tightly packed;
- synthetics: drum no more than half full;
- delicate fabrics: drum no more than one third full.

Laundry weights

The following weights are indicative:

bathrobe	1200 g
napkin	100 g
quilt cover	700 g
sheet	500 g
pillow case	200 g
tablecloth	250 g
towelling towel	200 g
tea cloth	100 g
night dress	200 g
ladies' briefs	100 g
man's work shirt	600 g
man's shirt	200 g
man's pyjamas	500 g
blouse	100 g
men's underpants	100 g

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 15

GB

Drying Programmes

Programme	Type of laundry	Options	Description of programme
Extra	Cotton and linen	**Dryness**	Drying thick or multi-layered textiles, e.g. terry towelling items
Intensive	Cotton and linen	**Dryness**	Drying thick textiles, e.g. terry towelling items, towels.
Cupboard	Cotton and linen	**Dryness**	Drying textiles of even thicknesses, e.g. terry towelling items, knitted items, towels.
Iron	Cotton and linen	**Dryness**	For cotton or linen laundry which are still to be put through a machine, e.g. bedding, table linen
Extra	Synthetics	**Dryness**	Drying thick or multi-layered textiles, e.g. pullovers, bedding, table linen.
Cupboard	Synthetics	**Dryness**	For thin textiles which are not ironed, e.g. easy care shirts, table linen, baby's clothes, socks, underwear.
Iron	Synthetics	**Dryness**	For thin textiles which are still to be ironed, e.g. knitted items, cotton shirts.
Mixed	Cotton Syntheticse	**Dryness**	Special programme for cotton and easy care, which can drying together in the same time.
Time	Synthetics Cotton		For drying individual items of laundry or for small volumes of less than 1kg. You can select a programme duration from 10 mins to 3 hrs in 10-minute steps.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 16

Drying programmes

Programme	Type of laundry	Options	Description of programme
Special **Jeans**	Cotton Cupboard dry	**Dryness**	Special programme for leisure clothing, such as jeans, sweat-shirts, etc., of different material thicknesses (e.g. at the cuffs and seams).
Special **Easy**	Synthetics		Special programme with anti-crease mechanism for easy care textiles such as shirts and blouses; for minimum ironing effort. The result depends on the type and quality of textiles. (The loading volume corresponds to approx. 4 to 5 shirts.) Recommendation: Place textiles in the dryer straight after spinning. Once dried, immediately remove textiles and place on clothes hanger.
Wool	Sweaters, Wollen pullover, Skirt, Pants		Wool is special programme for briefly treating woollens with warm air after they have been dried naturally, worn or stored for long periods. Wool fibres are aligned and the wool becomes soft and snugly
Sport **Shoes**	Shoes		For gentle drying of one pair of sportshoes, washed and spin-dried at 1000 rpm. Programme run times: between 30 and 180 minutes.
Special **Colling**	Cotton and linen Synthetics		Special programme, lasting around 10 minutes, for refreshing or gently cleaning textiles with commercially available dry cleaning sets. (Only use those products which are declared as suitable for the drier by the manufacturer; please observe the manufacturer's instructions for use.)

Max Cottons load:	7 kg	Max Special Mix load:	3 kg
Max Synthetics load:	3 kg	Max Special Jeans load:	7 kg
Max Time load:	1 kg		

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 17

Programme information

GB

Objective	Implementation
Adjusting the level of conductivity	Water contains, a variable quantity of limestone and mineral salts of which quantities vary according to geographical locations thus varying its conductivity values. Relevant variations of the conductivity of the water compared to those prefixed by the factory could slightly influence the residual humidity of the laundry at the end of the cycle. Your dryer allows you to regulate the sensitivity of the drying sensor based on conductivity values of the water by using the following procedure. To access adjustment mode: 1. Turn the programme selector dial to switch on the appliance. 2. In selection mode,press simultaneously the buttons DRYNESS and START. Press the buttons down until until «CO» appears on the digits. Adjusting the level of conductivity: Press the START/PAUSE button sequentially: the level of conductivity is indicated by the lighting of the horizontal hyphens. Normally, the appliance is factory-set to the highest level; however, certain models may be configured differently. **Memorizing the new setting:** Display / Conductivity / Approximate value uS/cm CO – / Low / <300 CO = / Medium / 300-600 CO ≡ / High / >600 Simultaneously press the buttons DRYNESS and START. Press the buttons down until the previous drying cycle time appears again on the display and the buzzer sounds.
O = Cancelling/OFF	To reset a programme and to switch off the machine turn the selector dial to **O**. Now a new programme can be selected.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 18

Care and cleaning

You must **DISCONNECT** the appliance from the electricity supply, before you can carry out any cleaning or maintenance work.


External cleaning

Use only soap and water and then dry thoroughly.

Important: do not use methylated spirit, diluents or similar products.


Cleaning the door

Clean periodically the interior part of the door to remove any fluff from the seals around the filter. Accurate cleaning ensures correct drying.




Cleaning the filters

Your dryer will only function well if the filters are clean. The filters collect all the fluff which accumulates during drying and they must therefore be cleaned **at the end of each programme**, before removing the laundry, with a damp cloth.
The light is on to remind you of this operation.




The filter in the inner door must be removed for cleaning.



Do not be alarmed by the amount of fluff. It is not due to excessive wear caused by the dryer.

All fabric loses fluff when drying but it goes un-noticed in the air. In a tumble dryer it simply collects in the filter.

After a while, a whitish patina due to detergent residue on laundry forms on the filters. When this occurs, clean the filters with warm water using a brush. Remove the filter in the door opening as per picture (it can be positioned with the tooth facing to the left or to the right).




Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 19


GB

Do not use the appliance without filters.





Cleaning the condenser unit

Clean the condenser when light ⇉ comes on.
The condenser is situated at the lower part of the cabinet behind a small door. To open the door, push the catch as per picture.
During the drying cycle or at the end, it is normal for water to be present on the surface of the condenser insertion.



To pull out the condenser, first turn the two red stops downwards and then remove the condenser unit holding it at the handle.





Clean it with a brush and rinse it under the shower if necessary. Also clean the outside, removing all fluff. Clean the rubber seal round the condenser cabinet and in the inner part of the small door with a damp cloth..

Important! Do not use pointed objects or utensils to clean the spaces between the plates, as this could damage the condenser and make it permeable. Re-fit the condenser, turn the red stops upwards and close the door.

Do not use this appliance if the condenser has not been fitted.

Emptying the water reservoir


Water extracted from the laundry condenses inside the machine and is collected in a reservoir. The reservoir must be emptied after each drying cycle to ensure efficient operation when the machine is next used. The pilot light reminds you this operation.


Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 20

Proceed as follows:

- Open the small door at the lower part of the cabinet
- Turn the yellow stop upwards
- Pull out the reservoir
- Open the small cover and let water flow down
- Close the small cover and re-insert the reservoir correctly
- Push it until it clicks and turn the yellow stop downwards to ensure it is firmly locked.
- Close the small door and press the START/PAUSE button again to allow the programme to continue.






The reservoir must be re-inserted correctly. If this is not done the pilot light comes on during next drying and the programme stops, leaving the laundry damp. The buzzer will sound for 1 minute.

After emptying and inserting the reservoir the START-button has to be depressed again to allow the programme to continue.

Handy tip: The condensed water may be used in a steam iron or to top up a battery, etc. In this case it must be filtered (e.g. through a coffee filter).

Cleaning the air intake grille

Using a vacuum cleaner remove the fluff from the air intake grille at the back of the appliance.



Cleaning the drum

When your laundry does not reach the desired degree of dryness, in other words, when it turns out either too dry or too damp, we advise you to clean the inside of the drum with a cloth soaked with vinegar.

This will eliminate the slight patina that has formed in the drum (due to residues of detergent and softeners used in the washing, and to the lime contained in the water), which prevents the probes from detecting the correct degree of dryness.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 21

GB

Something not working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. Before contacting your local Service Centre, please carry out the checks listed below.
During machine operation it is possible that the red Start/Pause pilot light flashes to indicate that the machine is not working.
Once the problem has been eliminated, press the Start/Pause button to restart the programme. If after all checks, the problem persists, contact your local Service Centre.

Malfunction	Possible cause	Solution
Dryer does not work.	•Mains plug is not plugged in or fuse is not working correctly.	• Plug in at mains socket Check fuse in fuse box (domestic installation).
	•Loading door is open.	• Close loading door.
	•Have you pressed the START/ PAUSE button?	• Press the START/PAUSE button again.
Drying results unsatisfactory.	• Wrong programme selected.	• Select a different programme the next time you dry
	• Lint filter clogged.	• Clean lint filter.
	• Heat exchanger clogged with lint.	• Clean heat exchanger.
	• Incorrect volume of laundry.	• Observe recommended loading volumes.
	• Ventilation slots in base area covered up.	• Uncover ventilation slots in base area.
	• Residue on inside surface of drum or drum ribs.	• Clean inside surface of drum and drum ribs
	• Conductance of water at installation site differs from standard setting of machine.	• Re-programme standard setting for degree of drying (see Programming options' section.
Loading door does not close.	• Loading door does not close.	• Install fine strainer and/or snap large mesh filter into place.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 22


Malfunction	Possible Cause	Solution
When pressing a button, the corresponding button flashes several times.	• Washing protection. After the start of the programme, the option can no longer be set.	• Turn the programme knob to “O”. Set the programme again
Drum light does not work	• Programme selector in “O” position. • Defective light bulb	• Turn programme selector to any programme • Replace light bulb (see next section).
When a button is pressed, Err appears in the multi-display.	• Washing protection. After the start of the programme, the option can no longer be set.	• Turn the programme knob to “O”. Set the programme again.
Programme inactive, Water reservoir full light illuminated.	• Condensate tank is full.	• Empty condensate tank, then start programme with START/PAUSE button.
Drying cycle ends shortly after programme starts. END light illuminated.	• Not enough washing loaded or washing loaded is too dry for selected programme.	• Select time programme or higher drying level (e.g. EXTRA DRY instead of INTENSIVE).
Drying cycle lasts an unusually long time. Note: After around 5 hours the drying cycle ends automatically (see „Drying cycle complete“)	• Lint filter clogged. • Heat exchanger clogged with lint. • DELICATE button pressed and load volume too big. • Load volume too big. • Laundry insufficiently pre-drained.	• Clean lint filter • Clean heat exchanger. • DELICATE is only suitable for use with loads of up to 3 kg! • Reduce load volume. • Laundry must be adequately pre-drained.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 23

GB

If you are unable to identify or solve the problem, contact our service centre. Before telephoning, make a note of the model, serial number and purchase date of your machine: the Service Centre will require this information.



IMPORTANT: if you call out an engineer to a fault listed below, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is under guarantee.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 24

Technical Data

Dimensions	Width Height Depth	60 cm 85 cm 58 cm
Electric connection Voltage - Overal power Fuse	Information on the electrical connection is given on the rating plate on the inner edge of the appliance door	
Depth with loading door open		109 cm
Maximum load	Cotton Synthetics	7 kg 3 kg
Use		domestic + 5°C + 35°C

CE This appliance conforms with the following EU Directives:
73/23/EEC dated 19.02.1973 Low Voltage Directive
89/336/EEC dated 03.05.1989 EMC Directive inclusive of Amending
Directive 92/31/EEC
93/68/EEC dated 22.07.1993 CE Marking Directive

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 25

GB

Consumption values			
Programme	**Programme duration (in minutes)**	**Energy consumption (in kWh)**	**Revolutions per minute**
Cottons Cupboard[1)]	125	3.92	1000
Cottons Iron[1)]	96	3.05	1000
Cottons Cupboard[1)]	110	3.39	1400
Cottons Iron[1)]	85	2.5	1400
Synthetics Cupboard[2)]	55	1.45	1200

z1) Max Cottons load: 7 kg
2) Max Synthetics load: 3 kg

The consumption values have been established under standard conditions. They may deviate when the machine is operated in domestic circumstances.


Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 26

Installation

Unpacking

All transit bolts and packing must be removed before using the appliance. Slide out the polythene bag with the polystyrene stuffing before using the appliance. Pull off adhesive strips from inside the machine on top of drum.



Should the appliance be moved, it must be transported vertically.

Do not install the appliance behind

– a door that locks


– a sliding door

– a door with a hinge that lies opposite the hinge of the appliance.

Remove the rack

The drying rack offers the possibility of drying washable woollen fabrics and sports shoes. The drying rack does not turn with the clothes-dryer drum. This allows the drying of woollen garments or sports shoes. When wet, the wool must be moved as little as possible because it tends to become matted. Sports shoes could damage the drum due to their weight.

1. Lift the rack out of the polystyrene protection used for transport and remove it from the clothes-dryer drum.



2. Remove the pieces of polystyrene from the drum one at a time.

3. Remove the elastic band from the rack and the rack containe.

Positioning

It is recommended that, for your convenience, the machine is positioned close to your washing machine.

The tumble dryer must be installed in a clean place, where dirt does not build up.

Air must be able to circulate freely all round the appliance. Do not obstruct the front ventilation grille or the air intake grilles at the back of the machine.

To keep vibration and noise to a minimum when the dryer is in use, it should be placed on a firm, level surface.

Once in its permanent operating position, check that the dryer is absolutely level with the aid of a spirit level. If it is not, raise or lower the feet until it is.

The feet must never be removed. Do not restrict the floor clearance through deep pile carpets, strips of wood or similar.

This might cause heat build-up which would interfere with the operation of the appliance.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 27


GB

Important

The hot air emitted by the tumble dryer can reach temperatures of up to 60°C. The appliance must therefore not be installed on floors which are not resistant to high temperatures. When operating the tumble dryer, the room temperature must not be lower than +5°C and higher than +35°C, as it may affect the performance of the appliance.

Stacking kit

A special stacking kit is available through your dealer, to enable the mounting of the dryer on top of a front loading washing machine with cover's depth between 48 and 60 cm. Read carefully the instructions supplied with the kit.



Door reversal

To make it easier to load or unload the laundry the door can be reversed. Reversing of the door is not possible if installed behind a door that opens in the opposite direction of the appliance.

This operation must be carried out by qualified personnel. Please contact the nearest Service Centre.

Electrical connection

Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

WARNING: THIS APPLIANCE MUST BE EARTHED.

The manufacturer declines any liability should this safety measure not be observed.

Before switching on, make sure the electricity supply voltage is the same as that indicated on the appliance's rating plate.


The appliance is supplied with a 13amp plug fitted.

In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS1362) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow	- Earth
Blue	- Neutral
Brown	- Live



Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 28

The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol ⏚ or coloured green and yellow.

WARNING:

A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard.

Ensure that the cut off plug is disposed of safely.

Permanent connection

In the case of permanent connection it is necessary that you install a double pole switch between the appliance and the electricity supply (mains), with a minimum gap of 3mm between the switch contacts and of a type suitable for the required load in compliance with the current electrical regulations.

The switch must not break the yellow and green earth cable at any point.

Important

The plug must be accessible after the appliance has been installed.

Special accessories

The following special accessories are available from your Electrolux Service Force Centre or your specialist dealer:

Intermediate installation kits for stacked washer and iron aid appliance:

These intermediate installation kits can be used to arrange the iron aid appliance and an automatic Electrolux washing machine (60cm wide, front loading) as a space-saving washer/iron aid stack. The automatic washing machine is at the bottom and the iron aid appliance is at the top.

Two versions can be supplied:

– without stacker plate

– with extractable stacker plate

Read the manual supplied with the installation kit carefully.

Levelling the appliance

The four feet of the appliance are preadjusted.

Large degrees of unevenness can be compensated for by individually adjusting the height adjustable screw feet.

To do this lift the appliance and turn the adjustable feet in or out.

Important Do not use pieces of wood, cardboard or such like to level out unevenness in the floor, but adjust the height adjustable screw feet instead.

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 29

Environment concerns

Packaging materials

The materials marked with the symbol ♺ are recyclable.
>PE<=polyethylene
>PS<=polystyrene
>PP<=polypropylene
This means that they can be recycled by disposing of them properly in appropriate collection containers.

Old machine

Use authorised disposal sites for your old appliance. Help to keep your country tidy!
The symbol  on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.

Ecological hints

GB

To save water, energy and to help protect the environment, we recommend that you follow these tips:

- Normally soiled laundry may be washed without prewashing in order to save detergent, water and time (the nvironment is protected too!).
- The machine works more economically if it is fully loaded.
- With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- Measure out detergent according to the water hardness, the degree of soiling and the quantity of laundry being washed..

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 30

Guarantee Conditions

Guarantee/Customer Service

Standard guarantee conditions

We, Zanussi Electrolux, undertake that if, within 12 months of the date of the purchase, this Zanussi-Electrolux appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option repair or replace the same FREE OF ANY CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's instructions.
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with, by any person not authorised by us.
- All service work under this guarantee must be undertaken by a Service Force Centre.
- Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.

Exclusions

- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Zanussi Electrolux manufacture which are NOT marketed by Zanussi Electrolux.

Service and Spare Parts

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact your local Service Force Centre by telephoning:

0870 5 929929

Your telephone call will be automatically routed to the Service Force Centre covering your post code area.

For the address of your local Service Force Centre and further information about Service Force, please visit the website at

www.serviceforce.co.uk.

Before calling out an engineer, please ensure you have read the details under the heading "Something Not Working".

When you contact the Service Force Centre you will need to give the following details:

1. Your name, address and post code.
2. Your telephone number.
3. Clear and concise details of fault.
4. The model and serial number of the appliance (found on the rating plate).
5. The purchase date.

Please note that a valid purchase receipt or guarantee documentation is required for in-guarantee service calls**.**

Customer Care

For general enquiries concerning your Electrolux appliance or for further information

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 31

on Electrolux products, please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.zanussi.co.uk

Customer Care Department Major Appliances

Addington Way Luton

Bedfordshire LU4 9QQ Tel 08705 727727(*)

(*)calls to this number may be recorded for training purposes.

European guarantee

This appliance is guaranteed by Electrolux, in each of the countries listed in the following page, for the period specified in the appliance guarantee or otherwise by law. If you move from one of these countries to another of these countries the appliance guarantee will move with you subject to the following qualifications:

- The appliance guarantee starts from the date you first purchased the appliance which will be evidenced by production of a valid purchase document issued by seller of the appliance.
- The appliance guarantee is for the same period and to the same extent for labour and parts as exists in your country of residence for this particular model or range of appliances.
- The appliance guarantee is personal to the original purchaser of the appliance and cannot be transferred to another user.
- The appliance is installed and used in accordance with instructions issued by Electrolux and is only used within the home, i.e. is not used for commercial purposes.
- The appliance is installed in accordance with all relevant regulations in force within your new country of residence.

The provisions of this European Guarantee do not affect any of the rights granted to you by law.

www.electrolux.com

Albania	+35 5 4 261 450	Rr. Pjeter Bogdani Nr. 7 Tirane
Belgique/België/ Belgien	+32 2 363 04 44	Bergensesteenweg 719, 1502 Lembeek
Česká republika	+420 2 61 12 61 12	Budějovická 3, Praha 4, 140 21
Danmark	+45 70 11 74 00	Sjællandsgade 2, 7000 Fredericia
Deutschland	+49 180 32 26 622	Muggenhofer Str. 135, 90429 Nürnberg
Eesti	+37 2 66 50 030	Mustamäe tee 24, 10621 Tallinn
España	+34 902 11 63 88	Carretera M-300, Km. 29,900 Alcalá de Henares Madrid
France	www.electrolux.fr	
Great Britain	+44 8705 929 929	Addington Way, Luton, Bedfordshire LU4 9QQ
Hellas	+30 23 10 56 19 70	4 Limnou Str., 54627 Thessaloniki

Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:42 Page 32

Hrvatska	**+385 1 63 23 338**	**Slavonska avenija 3, 10000 Zagreb**
Ireland	**+353 1 40 90 753**	**Long Mile Road Dublin 12**
Italia	**+39 (0) 434 558500**	**C.so Lino Zanussi, 26 - 33080 Porcia (PN)**
Latvija	**+37 17 84 59 34**	**Kr. Barona iela 130/2, LV-1012, Riga**
Lietuva	**+370 5 2780609**	**Ozo 10A, LT 08200 Vilnius**
Luxembourg	**+35 2 42 43 13 01**	**Rue de Bitbourg, 7, L-1273 Hamm**
Magyarország	**+36 1 252 1773**	H-1142 Budapest XIV, Erzsébet királyné útja 87
Nederland	**+31 17 24 68 300**	**Vennootsweg 1, 2404 CG - Alphen aan den Rijn**
Norge	**+47 81 5 30 222**	**Risløkkvn. 2 , 0508 Oslo**
Österreich	**+43 18 66 400**	**Herziggasse 9, 1230 Wien**
Polska	**+48 22 43 47 300**	**ul. Kolejowa 5/7, Warsaw**
Portugal	**+35 12 14 40 39 39**	**Quinta da Fonte - Edificio Gonçalves Zarco - Q 35 2774 - 518 Paço de Arcos**
Romania	**+40 21 451 20 30**	**Str. Garii Progresului 2, S4, 040671 RO**
Schweiz-Suisse- Svizzera	**+41 62 88 99 111**	**Industriestrasse 10, CH-5506 Mägenwil**
Slovenija	**+38 61 24 25 731**	**Electrolux Ljubljana d.o.o. Gerbiceva 98, 1000 Ljubljana**
Slovensko	**+421 2 43 33 43 22**	Electrolux Slovakia s.r.o., Electrolux Domáce spotrebiče SK, Seberíniho 1, 821 03 Bratislava
Suomi	**www.electrolux.fi**	
Sverige	**+46 (0)771 76 76 76**	**Electrolux Service, S:t Göransgatan 143,S-105 45 Stockholm**
Türkiye	**+90 21 22 93 10 25**	Tarlabaşý caddesi no : 35 Taksim İstanbul
Россия	**+7 095 937 7837**	129090 Москва, Олимпийский проспект, 16, БЦ „Олимпик“

Downloaded from www.Manualslib.com manuals search engine














Downloaded from www.Manualslib.com manuals search engine

125987340.qxp 2007-03-16 11:43 Page 34

www.electrolux.com

www.electrolux.co.uk



125 987 341 -00- 12072007

Downloaded from www.Manualslib.com manuals search engine