



FR Lire attentivement le livret consigné de sécurité et ce livret avant la première utilisation
EN Read safety instructions and booklet carefully before using for the first time.
DE Lesen Sie vor der ersten Benutzung die Sicherheitshinweise und die Broschüre sorgfältig durch.
NL Neem vóór het eerste gebruik dit boekje en het boekje met de veiligheidsvoorschriften aandachtig door.
IT Leggere con attenzione il libretto sulle norme di sicurezza e questo libretto, al primo utilizzo.
ES Lea detenidamente las instrucciones de seguridad y este folleto antes de utilizar el aparato por primera vez.
PT Leia atentamente as instruções de segurança bem como este folheto antes da primeira utilização.
EL Διαβάστε προσεκτικά το φυλλάδιο με τις οδηγίες ασφαλείας καθώς και αυτό το φυλλάδιο πριν χρησιμοποιήσετε τη συσκευή για πρώτη φορά.
DA Læs hæftet med sikkerhedsanvisninger og dette hæfte omhyggeligt, inden apparatet tages i brug første gang.
SV Läs häftet med säkerhetsinstruktioner och det här häftet nog innan du använder apparaten första gången.
FI Lue turvallisuus- ja käyttöohjeet huolellisesti ennen ensimmäistä käyttökertaa.
NO Les nøye heftet med sikkerhetsinstruksjoner og dette heftet før første gangs bruk.
TR Kullanmadan önce güvenli kullanım kitapçığını ve bu kitapçığı dikkatlice okuyun.
RU Перед первым использованием прибора внимательно ознакомьтесь с правилами техники безопасности и данной инструкцией.
UK Прочитайте інструкції з техніки безпеки і цю брошуру перед використанням уперше.
KK Бірінші рет қолданарда қауіпсіздік нұсқаулығын мұқият оқып шығыңыз.
RO Citii cu atenție manualul cu instrucțiunile de siguranță și această broșură înainte de prima utilizare.
SL Pred prvo uporabo natančno preberite navodila za varno uporabo in ta navodila.



8080015872/01

SR Pre prve upotrebe pažljivo pročitate knjižicu s bezbednosnim uputstvima i ovu knjižicu.
HR Molimo da prije prvog korištenja pažljivo pročitate sigurnosne upute i priručnik za korištenje.
BG Преди прва употреба прочитайте knjižicu sa sigurnosnim uputama i knjižicu o upotrebi.
LV Lugeje enne esimest kasutuskorda tähelepanelikult ohutusnõudeid ja seda brošüüri.
LT Pirms pirmās lietašanos uzmaningiai išlošiet drošības nurodymus ir šią informaciją.
PL Przed pierwszym użyczeniem urządzenia przeczytaj uważnie książkę z zasadami bezpieczeństwa oraz niniejszą instrukcję.
CS Před prvním použitím si pozorně přečtěte brožuru „Bezpečnostní opatření a použití“.
HU Az első használat előtt figyelmesen olvassa el a biztonsági előírásokat szóló broszúrát és a jelen broszúrát.
TH อ่านคำแนะนำความปลอดภัยก่อนใช้เครื่องทุกครั้ง
KO 처음 사용 전 안전 지침과 현 책자를 잘 읽어 주시기 바랍니다.
VI Trước khi sử dụng, đọc kỹ hướng dẫn an toàn và đọc kỹ tờ hướng dẫn.
ZH 使用前，請仔細閱讀安全維護手冊和說明書。
MS Sila baca buku arahan keselamatan dan buku ini sebelum menggunakan untuk kali pertama.
AR اقرأ كتاب تعليمات الأمان بعناية قبل أول استخدام.
FA قبل از استفاده دفترچه راهنمای ایمنی و این دفترچه را مطالعه کنید.



* Selon modèle/Depending on model
Je nach Modell/Afhankelijk van het model
Secondo il modello/En función del modelo
Consoante o modelo/ανάλογα με το μοντέλο
Modelafhængig/Beroende på modell
Mallista riippuen/Avhengig om modell
Modele göre/V závislosti od modelu
залежно від моделі/згідно з байланьсти
in functie de model/Giede na model
U zavisnosti od modela/Ovisno o modelu / Ovisno o modelu
В зависимости от модели/Сoltuvalt modelist
Atbilstoši modelim/Priklusomai nuo modelio
Podľa modelu/Modelti fuggően
ແຕ່ຕາມກຸ່ມໂມດລ໌/모델에 따라
Tùy theo mẫu /視乎型號而定
Bergantung pada model
بر حسب مدل/حسب الموزن

2.1 *
Illustrations showing correct and incorrect use of the whisk attachment.
1. Correct use: whisk in a glass.
2. Incorrect use: whisk in a plastic cup.
3. Correct use: whisk in a measuring cup.
4. Incorrect use: whisk in a measuring cup with liquid.
5. Correct use: whisk in a measuring cup.
6. Incorrect use: whisk in a measuring cup with liquid.

2.2 *
Illustrations showing correct and incorrect use of the chopper attachment.
1. Correct use: chopper in a measuring cup.
2. Incorrect use: chopper in a measuring cup with liquid.
3. Correct use: chopper in a measuring cup.
4. Incorrect use: chopper in a measuring cup with liquid.

3 * 450/500/600ml
Illustrations showing correct and incorrect use of the chopper attachment in a measuring cup.
4 * 150ml
Illustrations showing correct and incorrect use of the chopper attachment in a measuring cup.

6 *
Illustrations showing correct and incorrect use of the whisk attachment.
5 *
Illustrations showing correct and incorrect use of the whisk attachment.

Table with 4 columns: icon, correct/incorrect status, correct/incorrect status, correct/incorrect status. Rows show various accessories and their compatibility with different mixer models.

Table with 4 columns: icon, correct/incorrect status, correct/incorrect status, correct/incorrect status. Rows show various accessories and their compatibility with different mixer models.

Table with 6 columns: icon, icon, icon, icon, icon, icon. Rows show various accessories and their compatibility with different mixer models.

If your appliance does not work, check it is properly connected to the mains and the power cord is in good condition.
If the appliance still does not work? Contact an approved service centre (see the service booklet).

Ako váš aparat ne radi, proverite da li je pravilno povezan na električnu mrežu i da li je kabl u dobrom stanju.
Ako uređaj još uvijek ne radi? Obratite se ovlaštenom servisu (vidi listu u knjižici o postrođajnim uložacima).